

VCube
HD VIDEO SYSTEM

Essentials



No part of this documentation may be reproduced in any form whatsoever or be stored in any data retrieval system without prior written permission of the copyright owners.

This documentation is supplied on an as-is basis. Information contained within this documentation is subject to change at any time without notice and must not be relied upon.

All company and product names are [™] or Registered Trademarks [®] of their respective owners. Windows Vista, Windows XP and Windows 2000 are trademarks of Microsoft Corporation.

Merging Technologies makes no warranties express or implied regarding this software, its quality, performance, merchantability or fitness for a particular purpose. The software is supplied "as is" you, the purchaser, are assuming the entire risk of the results of using this Merging Technologies software.

In no circumstances will Merging Technologies, its owners, directors, officers, employees or agents be liable to you for any consequential, incidental or indirect loss or damages including loss of time, loss of business, loss of profits, loss of data or similar resulting from the use of or inability to use the Merging Technologies hardware and or software or for any defect in the hardware software or documentation.

© Copyright Merging Technologies Inc. 2011. All rights reserved



Introduction	5
Thank you!	5
Scope of this Guide	5
About this Guide	6
Assumptions	6
Conventions	6
Important Note	7
Introduction to VCube Essentials	8
What is VCube Essentials?	8
Experienced VCube Users	8
Installing VCube Essentials	8
Creating a First VCube Essentials Composition	9
Quick Settings	11
Synchronizing VCube Essentials with Pyramix	13
Managing VCube Essentials Resources	16
Output Page Diagnostic Tools	16
System Tab	17
Playback Info Tab	19
Buffer & Cache Tab	21
Index	23



Document revision-02

Date: 5th-July-2011

Introduction

Thank you!

Thank you for purchasing Merging Technologies VCube Essentials video player software package! VCube is the "Swiss Army Knife" of video players with options available for playing back all common (and not so common) SD and HD file formats. Whether replacing an existing QuickTime® Video Player when upgrading to Pyramix 7, or as a packaged bundle with a new Pyramix 7 system, VCube Essentials is your entry into the world of VCube. Essentials enables you to use QuickTime® or Windows® Direct Show compatible video files in a single player. Optional support for other formats can be purchased from your Merging Technologies Sales partner.

Note: IMPORTANT! - The first thing you need to do is register your software to acquire your VCube key(s) and to be included in our user support list.

Please also subscribe to the User Forum at:

<http://www.merging.com/forum/>

Scope of this Guide

This guide aims to help new users of VCube Essentials video player software (catalog: PSO-VCP) to get up and running as quickly as possible and to help users as to appreciate the technical considerations and possible limitations of VCube Essentials v3 in a multi-task environment alongside Pyramix v7 in one machine.



About this Guide

Assumptions

This User Manual and the other documentation assume you are thoroughly familiar with PCs and Windows terms and concepts. If the PC is new, please ensure the machine is working correctly before attempting to install VCube.

Note: Although VCube version 3 runs under the 32 bit versions of Windows XP, Windows Vista and Windows 7, it does not support the “Aero” style transparency display features present in Windows Vista and Windows 7. This will be turned off automatically for the duration of the VCube session.

Conventions

Conventions used in this document:

Names found on screens and in menus are shown in bold. E.g. **Information & Settings**

Menu and sub-menu selections are shown like this:

User-Interface > Output > Show Buffer Tab

Which means:

Go to the **User-Interface** pull-down menu, mouse down to the **Output** sub-menu, mouse down to the **Show Buffer Tab** entry and **Click**.

References to VCube Settings Tabs are shown thus:

Settings : Formats & Sync : Composition Video Format : Height

Which means:

In the Settings Page accessed via **Settings > Show All Settings** click on the **Down Arrow** and **Click Format & Sync** to open the Tab. In the **Composition Video Format Section** the **Height** field is the one we are interested in.

Keyboard Shortcuts are shown thus: **[Ctrl + Num 9]**.

The VCube User Interface uses a number of buttons. These are dark when unchecked (inactive, not selected) and orange when checked (active, selected) The state of these buttons is referred to as **checked** or **unchecked**.



VCube button states

In the screenshot above the **Transparent Overlay Box** is inactive (unchecked) and **Chase TimeCode** is active (checked).

Documentation

Automatically installed with VCube and available under the **Help** menu or **[F1]**.

To ensure the document is visible please uncheck **TopMost** in **Settings > Show User Interface Tab : Display - Manual Resize** or use **[Ctrl + Shift + Alt +P]** to open the page.

All the documentation is in the Adobe Acrobat pdf format. (.pdf file extension)

In order to read the documentation you will need to have **Adobe Acrobat Reader V5** or later installed on your computer.

Other documentation can be found in the Windows **Start** menu in **All Programs > VCube > Docs**. Please check for the most recent versions at:

<http://www.merging.com>



Note: All features described in the documentation are available in the **Advanced Mode**. If the user-interface is set to **Simple Mode** some features may remain hidden or unavailable. To change the UI Mode:

User Interface > WorkSpace > UIMode: Advanced [Alt + F3]

User Interface > WorkSpace > UIMode: Simple [Alt + F1]

Navigation

In electronic form, all the **Contents** and **Index** entries and **Cross-references** are hyperlinks. I.e. Clicking on them will jump to the relevant item.

ToolTips

VCube software is equipped with 'ToolTips'. Hovering the mouse cursor over a tool icon pops-up a box with the name of the function and the keyboard shortcut (where applicable).

Support

If you cannot find an answer to a query in the documentation, please consult the on-line support at:

<http://www.merging.com>

where you will find answers to F.A.Q.s (Frequently Asked Questions) and further support.

Multiple Monitors

VCube supports 2 screen extended desktop operation. Depending on the Vcube version and the hardware available, analog and digital video outputs are available to feed monitors and or projectors.

Important Note

VCube is not only a very powerful video player/recorder, it is also a highly configurable one, the User Interface as much as the Video and Audio. Therefore screenshots in this document may differ from what you see on screen.

PLEASE DO NOT PRINT THIS DOCUMENT UNLESS ABSOLUTELY NECESSARY
SAVE TREES AND INK BY USING THE HYPERLINKS



Introduction to VCube Essentials

For many years the **Virtual Transport** module in combination with the QuickTime® Video player and the Direct Show Video Player, either sold as stand-alone options or included in certain Pyramix software bundles, has provided the opportunity to play back video clips efficiently, synchronized with Pyramix on the same CPU, with very little encumbrance to the system itself. The combination of the Direct Show Player to handle playback of video files encoded with Windows® based codecs and the QuickTime® Player for QuickTime® based files meant that users had to either choose between the two groups of possible file formats when preparing Pyramix projects or had to purchase both optional players in order to be able to accommodate the highest number of video file types. However, since the introduction of these two players, Merging Technologies has co-developed, released and continued the fervent development of the highly sophisticated stand-alone video player/recorder, "VCube". Now that VCube has reached full maturity with its third software revision (as of July 2011) Merging is confident that the time has come to gradually phase out the QuickTime® Video Player option and eventually to discontinue the Direct Show Video Player altogether in favor of VCube. This is why we created the VCube Essentials Video Player option for Pyramix.

What is VCube Essentials?

VCube Essentials is a full VCube HD player equivalent in functionality to a VCube LE system. It enables almost any type of video file to be loaded and played out whether they are QuickTime® based or Windows® based and allows for the addition of specialized decoder options like MXF, MPEG2-HD (Sony XDCam HD), DVCPro HD, VC-3 (Avid® DNxHD) and AVC Intra (Panasonic P2).

VCube Essentials also allows for the optional addition of interchange formats from major video editing stations like OMF, AAF and Apple FCP® XML.

Experienced VCube Users

Those of you already familiar with the VCube installation process, and general operation, loading video into the VCube time line etc., will be happy to learn that the VCube Essentials user interface is identical to all other VCube versions. So, you may wish to skip the following sections and go straight to the **Managing System Resources of VCube Essentials** section to discover the built-in tools that may help you better manage your VCube Essentials experience when pushing the envelope of your system's resources comfortably to the maximum in full HD.

Installing VCube Essentials

This section describes how to install the VCube Essentials for the first time on your Pyramix workstation.

Minimum requirements:

For a list of the IT hardware currently recommended by Merging please consult our website under the section: **PC Config - Recommended/ Required**

<http://www.merging.com/pages/pconfig>

Upgrading from Merging Technologies QuickTime® or Direct Show Players

For users who are migrating from Merging's QuickTime® Video Player or Direct Show Video Player to VCube Essentials on an existing Pyramix workstation you **must** run the VCube installer that corresponds to your **exact** Pyramix build number and import your **VCube Essentials MT Security Key**, (as you would with any other key) provided by Merging through your reseller, to activate it.

1. Verify that Pyramix and VCube have exactly same installer versions prior to installing VCube Essentials.
 - Begin by determining the exact version of your Pyramix 7 installation by carefully taking note of the **build number** indication in the Pyramix splash screen as it launches, by noting the **build number** in **Help > About...** or by looking at the build numbers indicated in the names of the Pyramix and VCube installation files.



- If the VCube Essentials build number does not match that of Pyramix, logon to the **Support / Download** page on the Merging Technologies website and obtain the correct, corresponding releases of both installers.
- 2. Launch the VCube installer and proceed with the installation of VCube to your system in the same location where Pyramix is already installed.
- 3. Import your **VCube Essentials Activation Key**. This key is included in the e-mail notification provided by your local Merging Technology sales partner.
- 4. To import the **Key** save the *.mtk attachment to your PC and double-click on it to automatically open the **MT Security Settings** panel or open the **MT Security Settings** panel manually and click the **Import Key(s)** button to locate and select the *.mtk key manually.
- 5. Launch the **VS3 Control Panel** from **Start > All Programs > Merging Technologies > VS3 Runtime**.
- 6. Choose **VCube** in the **Application** drop-down menu to show the VCube audio interface options.
- 7. Choose the appropriate **ASIO** driver to be used by VCube in the **Driver Name** drop-down menu and click on **OK** to validate.
- 8. Launch VCube and, if prompted to choose the first startup mode, check the **Software Mode: SE, LE, XE** button and click on **OK** to launch VCube for the first time.

Tip: It is generally good practice to always **launch Pyramix first** (and wait for it to initialize fully) followed by VCube on a multi-tasked system.


Note: For more comprehensive installation details please consult the Pyramix and VCube Installation Guides respectively. These are available on our website in the **Support > Downloads** page.

<http://www.merging.com/download>

Creating a First VCube Essentials Composition

There are several ways to load Media Files into the VCube timeline. The simplest way is to open a file by using the **Media File Browser** located in the **VCube Settings Pages**. (You can also access it via **File > Import > Media File Browser (Ctrl + Shift + O)** or in **User Interface > Settings Tabs > File > Show Media FileBrowser Tab**.) Browse to the required Media File and use the **Load & Auto-Config** function.

Tip: To display all the VCube **Settings** pages use the **F2** shortcut key.




Media File Browser header

1. Open the **Media File Browser** and click on the three periods (full-stops) ... button to the right of the **File Path** field to open a standard Windows **Browse For Folder** dialog box and navigate to the folder where the Media File you wish to play is located.
2. Select the folder containing the Media File and click **OK** to display the Media Files that VCube recognizes in the Media File Browser.
3. Click once on the Media File itself in the Media File Browser and then click on the **Load & Auto-Config** button to adjust VCube's settings automatically to match the format of the Media File itself and to place the Media File on the timeline at its original TimeCode.
 - If the video has no TimeCode value but you wish to place it at a specific TimeCode start value, then another way to place a clip into the time line would be to place the Playhead Cursor at the desired



TimeCode in the Timeline and then use the **Place to Cursor** button in the Media File Browser. For further methods of offsetting clips or offsetting the incoming TimeCode used to synchronize VCube, please refer to the VCube User Manual.



Media File Browser bottom buttons

Note: VCube only displays recognized media files and will mask any other files present in a folder.

Note: From the Media File Browser you may access any folder on any drive in your local machine or available on your network to stream media instantly from any location without importing it or converting it.

Note: Please see next section: **Quick Settings** before attempting Playback.

Quick Settings

Quick SD Settings

Current configuration

Size	1920x1080
Field Order	2 Fields (Interleaved - Lower First)
Pixel Aspect Ratio	1.067
Composition Frame Rate	NTSC (29.97 fps)
TC Frame Rate	NTSC (29.97 fps)
Mykerinos Video RefFormat	PAL (625 50.00 Hz)
Audio Sampling Rate	48000 Hz

Reference source

PAL

PAL 4/3 D1	Apply
PAL 4/3 DV	Apply
PAL 16/9 D1	Apply
PAL 16/9 DV	Apply

NTSC

NTSC 4/3 D1	Apply
NTSC 4/3 DV	Apply
NTSC 16/9 D1	Apply
NTSC 16/9 DV	Apply

Close

Quick HD Settings

Current configuration

Size	1920x1080
Field Order	2 Fields (Interleaved - Lower First)
Pixel Aspect Ratio	1.067
Composition Frame Rate	NTSC (29.97 fps)
TC Frame Rate	NTSC (29.97 fps)
Mykerinos Video RefFormat	PAL (625 50.00 Hz)
Audio Sampling Rate	48000 Hz

Reference source

Mode :

☒ Normal
 ☐ DVCPro - HD
 ☐ HDV

720p

720p 50.00 Hz	Apply
720p 59.94 Hz	Apply
720p 60.00 Hz	Apply

1080i

1080i 50.00 Hz	Apply
1080i 59.94 Hz	Apply
1080i 60.00 Hz	Apply

1080p sf

1080p sf 23.98 Hz	Apply
1080p sf 24.00 Hz	Apply

1080p

1080p 23.98 Hz	Apply
1080p 24.00 Hz	Apply
1080p 25.00 Hz	Apply
1080p 29.97 Hz	Apply
1080p 30.00 Hz	Apply

1080p / p sf - 2K

2048 x 1080p 23.98 Hz	Apply
2048 x 1080p 24.00 Hz	Apply
2048 x 1080p sf 23.98 Hz	Apply
2048 x 1080p sf 24.00 Hz	Apply

Close

VCube SD and HD Quick Settings

Tip: When creating a new composition by placing Media Files into the VCube Timeline manually with the **Load& Auto-Config** button, **ALWAYS** use the **Quick Settings** functions to preset the VCube to the appropriate format in which you wish to display your media before attempting playback. The **Quick Settings** are accessed via the **Settings** menu or by keying **Alt + F5 (SD)** or **Alt + F6 (HD)**.



Quick Settings

VCube can play virtually any video format in the timeline and will compensate for frame rate, resolution, aspect ratio, pixel size, color depth down sampling or size differences automatically to the best values possible but the overall settings should be aligned to a single video format listed in either one of the two Quick Settings menus. These Quick Settings help to avoid accidental user omission of an important setting that may hinder the proper display of video played back by VCube.


Using the Quick Settings aligns up to 11 parameters automatically, spread out over the various menus within VCube. So get into the habit of **always** using the **Quick Settings** every time you begin a new Composition and adjust individual settings afterwards only if necessary to fit your needs. All settings modified with a Quick Settings load are subsequently saved in the Composition and recalled when the Composition is reloaded.

For more details about the individual settings in VCube please refer to the VCube User Manual.

Synchronizing VCube Essentials with Pyramix

Currently, as of Pyramix v7.1 and VCube v3.1, synchronization of the two programs is achieved via **Virtual Transport**. The following checklists will help you set up all three programs with adequate settings.


Pyramix Checklist for Synchronization



Pyramix Settings All Settings > Remote Control > Virtual Transport page

1. Launch Pyramix
2. Open the **All Settings** menu in Pyramix (**Alt + G**)
3. Open the **Remote Control > Virtual Transport** sub menu
4. Tick the **Enable Virtual Transport Communication** box
5. Tick the **Automatically Set as Clock Master** box
6. Tick the **Automatically Set as Time Code Master** box
7. Click **OK** to save settings and activate Virtual Transport

VCube Checklist for Synchronization



VCube Settings page : Format & Sync Tab

1. Launch VCube Essentials
2. In the **Settings** page open the **Format & Sync** Tab
3. Scroll down to the **Synchronization** section and check the **Follow VT** button to activate it
4. Un-check the **VCube as VT Clock Master** button

Virtual Transport Checklist for Synchronization



VT - Client pane

1. Open **VT** from the Windows Task Bar (it will be hidden in the notification area by default under Windows 7 so click on the tiny triangle in the bottom right side of the task bar to show the hidden VT icon)
2. Click on the **Client** button (yellow **CL**)
3. In the **Pyramix Client** verify that the following boxes are checked on:



- **Clock Master**
 - **TC Master**
 - **Lock**
4. In the Pyramix Client verify that the **Chase** check box is off
 5. In the VCube client verify that the following check boxes are checked on:
 - **Lock**
 - **Chase**
 6. In the **VCube** Client verify that the following boxes are checked off:
 - **Clock Master**
 - **TC Master**

Note: Note: Take special care to always use the same TimeCode base in both Pyramix and VCube to insure proper synchronization through VT. I.e.: **25** to **25**, **29.97** to **29.97**, **23.98** to **23.98** etc.

VT cannot synchronize Pyramix and VCube if they do not have the same frame rate. Any change in either Pyramix or VCube alone to a new frame rate will automatically change VT to match but not the other program that has not yet been changed so remember to change them both.



Managing VCube Essentials Resources

Pyramix and VCube are powerful real-time audiovisual applications, both with the potential to play out massive amounts of sound and HD picture data while recording audio and performing real-time editing processes. When the resources of your workstation are understood and well balanced, multi-tasking of Pyramix and VCube is a powerful audiovisual tool. Typically VCube can handle all video files in the SD formats efficiently and the vast majority of HD video file formats elegantly and effortlessly on the latest multi-core Intel® CPU platforms. However, some HD video files may prove to be highly CPU or disk intensive and tip the scale sending any system "over the red line" causing stalls and skipped frames during playback. Thus it is important to know how to determine if a video file is simply *too demanding* for real-time play out by using VCube's built-in resource diagnostic meters.

Output Page Diagnostic Tools

The Output page has three diagnostic monitoring pages which enable you to read the current status of different points of system resource consumption and potentially detect a "bottleneck" which is hindering smooth and reliable playback of the most demanding HD video files.

1. **System**
2. **Buffer**
3. **Playback Info**


So if you encounter a file that just does not play out smoothly, check these diagnostic tools first in order to determine where the bottleneck is so that you may find a solution such as:

1. Changing the buffering scheme of VCube
2. Moving the Media file to a faster drive
3. Replacing the Media File itself in favor of a new version encoded using a faster, more efficient codec than that used for the original encode.

Note: VCube Essentials is sold as a player only, devoid of any recording, rendering or wrapping capabilities, so it may be necessary to use another VCube version with these capabilities activated (VCube Turnkey, XE or SE versions) or a 3rd party video processing software or editing station to re-render or down-convert the most resource hungry HD files that persistently cause system stalls.

System Tab

The first diagnostic tool in the Output page is the **System Tab**. This shows a real-time graph of the overall **CPU** usage and the **Memory** consumption of VCube itself. The CPU display shows a graphical percentage plot of each CPU core for use by VCube under Windows to the right and on the left an average percentage of all cores combined.



Output Page - System Tab

CPU


In order to understand what is to be investigated while comparing the CPU consumption and the other indicators in the diagnostic tabs, it is first necessary to understand the two extremes of the HD video file scale.

At one end of the scale is video that is encoded with a high data compression ratio and therefore uses a large amount of CPU resources at the moment of decoding but has a very small file size and therefore a reduced bit rate (requiring less disk performance). At the other extreme are totally uncompressed (**RGB**, **YCrCb**, **YCbCr**) type video formats that require almost no CPU usage (due to the absence of decoding) but require huge amounts of disk data throughput due to extreme bit rates.

So if your CPU is exceeding 100% while playing a certain file, the file is most likely highly data compressed or encoded with a codec that is too CPU intensive for your system. Try increasing the Playback Buffer or use a file that is encoded with a lower data compression ratio (higher bit rate) or encoded with a different and more efficient codec altogether.

Memory

Below the CPU graphs is a graph showing the estimated memory consumption of VCube. This memory consumption graph does not include the other processes running under Windows so it is good to compare the memory consumption graphs of the **Windows Task Manager** under the **Performance** tab with that of VCube for comparison purposes. To access the Windows Task Manager key **Ctrl + Shift + Esc** (or **Ctrl + Alt + Del** and choose **Start Task Manager**) and click on the **Performance** tab.



Windows Task Manager - Performance Tab

Memory consumption is critical in any system and VCube can potentially consume large amounts of memory depending on three main factors:

1. Resolution and frame rate of the VCube Timeline.
2. Number of Frames set in the Playback Buffer (**Settings** Page : **Buffer & Cache**).
3. The codec used to encode the video file in question.
4. The number of Clips playing simultaneously in the Timeline at any given moment

Warning: The system memory consumption should be kept as low as possible and never exceed approximately 75-80% of the total amount of RAM installed in the system. This is especially critical in 32-bit versions of Windows as only the first 3 gigabytes of RAM are actually addressable by Windows and therefore VCube should never take so much of the RAM for itself as to hinder Pyramix and Windows itself. Exceeding the 80% mark of memory consumption for any reason can render any system unresponsive and even critically unstable.

The Playback buffer can be either an ally or an enemy in cases where HD video files do not seem to playback well. Increasing the Number of Frames in the Buffer helps to remedy playback stalls but increases the memory consumption footprint of VCube proportionally leaving less memory for Pyramix and Windows.

When determining what the optimum size should be, begin with the default value of **7** Frames and increase the number of Frames incrementally until playback is satisfactory whilst keeping an eye on memory consumption during playback. There is no point pushing the buffer to an excessive value in the hope that you will have smooth playback all the time if it means sacrificing precious memory elsewhere and causing the system to become unstable. For this reason keep the buffers as small as possible without stalling. If an increase in Playback Buffer size does




not remedy playback stalls then investigate further to determine if your media volume is adequately outputting media to VCube or use a smaller more efficient version of the HD video encoded in a different format or at a different bit rate.

Buffer Tab

The Buffer tab shows three graphical plots:

1. **Available Video Buffer**
2. **Queued Buffer**
3. **Available Audio Buffer**



Output Page - Buffer Tab

All three of these graphs show a direct correlation of the scale of available buffer resources in relation to the **Playback Buffer** frame size. Raising or lowering the number of frames in the buffer also raises or lowers the scales of the graphs. The **Available Video Buffer** and **Available Audio Buffer** scales are subtractive and the red line is lower as the buffers are used in playback while the **Queued Buffer** graph is additive and rises to show the overall headroom of both the Video and Audio buffers. None of the three buffers should ever bottom out during playback. If they do this indicates a stall in the system due either to a CPU problem, a data throughput problem from the Media Volume to the playback engine or even possibly a PCI(e) bus problem on the Motherboard due to a saturation of activity in the system (although this is rare).


The Buffers should remain relatively flat and stable without bottoming out so, once again, watch for dips in buffers and adjust the Number of Frames in the Playback Buffer accordingly without over consuming system memory.

Playback Info Tab

The **Playback Info** tab shows two graphical plots with **Video Disk Read (ms)** and **Audio Disk Read (ms)** timings and 11 individual diagnostic numeric value boxes. The principal indicators, which are relevant to VCube Essentials and therefore that will be explained here, are:

1. **Video Disk Read** graph
2. **Audio Disk Read** graph
3. **Read Drop** counter
4. **Read Time Average**
5. **Preview Drop** counter

6.Current FPS



Output Page - Playback Info Tab

Note: The remaining counters not listed above either do not apply to VCube Essentials due to the absence of an AJA® video board in the system or are not helpful in determining the cause of poor playback.

Video and Audio Disk Read graphs

The **Video** and **Audio Disk Read** graphs show the delays between the moment a media frame is requested from a disk volume and the moment it is available for use by VCube. These graphs therefore show the transfer time before the media is decoded and placed into the **Playback Buffer**. So the number of Frames in the buffer itself has no bearing on this information. As the bit-rate of the media increases so will the time it takes to read it from a disk volume. The overall transfer time in milliseconds, displayed in the upper right corners of each graph as well as plotted out in red, should never exceed the delay in milliseconds of the duration of one frame of video of the current VCube playback engine. Just to be on the safe side it should even be considered that a safe ratio of Disk Read delay to a single frame of video should be about half that of the time of a single frame to allow for occasional media volume transfer bottlenecks. These bottlenecks may occur in very short periods of time but must never exceed the remaining number of frames in the Playback Buffer. That is what the Playback Buffer is there for. Here is a quick table to show the length of a single frame of video in milliseconds for each major frame rate and the subsequent approximate target Disk Read delays that should give reliable play out performance.

Frame rate	Milliseconds	Safe Delay
24	41.67	20.83-30
25	40	20-30
29.97	33.37	16.68-28

If the **Disk Read** delays systematically exceed the safe delay values then the Buffer will quickly empty out causing stalling and skipped frames during playback.

Remedy: Use higher performance disk volumes that transfer the media files uninterrupted and fast enough for VCube to process them and put them into the Play Buffer continuously or use a Media File with a lower bit rate.



Read Drop Counter

The **Read Drop** Counter shows a continuous display of how many frames of video were dropped (due to insufficient throughput of the media volume to the VCube playback engine) during a single playback pass. If the raw media data arrives late to VCube because the disks are too slow, then VCube does not even have a chance to process them.

Note: Stopping and restarting playback resets the values in all the counters so consult them during playback.

Read Time Average

The **Read Time Average** shows the delay of processed video frames (post playback engine) from disk-to-Playback Engine to the Playback Buffer. This value must never exceed the Safe Delay values listed above for a succession of frames larger than the size of the Number of Frames in the Playback Buffer. If it does the result is a playback stall.

Preview Drop Counter

The **Preview Drop** counter shows the number of frames dropped in the VCube Preview Window running on the display engine of the computers graphic board (as opposed to video frames dropped on the AJA board shown in the **Video Drop** counter). When in doubt as to if VCube is dropping frames, consult this counter during playback. It is also displayed at the lower left-hand side of the VCube interface **Drop=0**.

Current FPS

The **Current FPS** counter shows the real-time frame rate per second of the VCube playback engine. If this value varies after the initial lock cycle of VCube is established then VCube has detected a drift in the playback speed. This is most likely due to a problem between the lock reference of VCube and the incoming TimeCode value. It may also be due to a conflict between the frame rate of VCube and that of Pyramix or Virtual Transport.

Remedy: Verify that all three are running at the same frame.

Buffer & Cache Tab

The **Buffer and Cache** Tab located on the **Settings** Page is crucial to the proper setup of VCube and, as discussed in the previous section, must be carefully adjusted for the type of Media being played back by VCube.

It has been found that the best general default parameters are:

1. Start with a Buffer value of **7** for SD picture and **15** for HD picture
2. Deactivate all four of the read and write caches and restart VCube for the cache changes to take effect.

Adjustments may be made to facilitate certain HD files that prove to be problematic during playback but the Buffer itself should be gradually increased and not just set to it's maximum value at all times which (like any buffer) may seriously hinder the performance and reliability of the system by consuming excessive amounts of precious RAM, especially on a 32-bit operating system.

Note: The Multi Thread Seeking button has negligible effect due to the vast improvements in IT hardware in general since the introduction of VCube v1.0 and may be left off.

For further detail and contact information visit Merging Technologies' website:

www.merging.com





Index

A

About this Guide 6
Advanced Mode 7
Assumptions 6

B

Buffer & Cache Tab 21
Buffer Tab 19

C

Conventions used in this document 6
CPU 17
Creating a First VCube Essentials Composition 9
Current FPS 21

D

Documentation 6

E

Experienced VCube Users 8

I

Installing VCube Essentials 8
Introduction 5
Introduction to VCube Essentials 8

M

Managing VCube Essentials Resources 16
Memory 18
Minimum requirements 8
Multiple Monitors 7

O

Output Page Diagnostic Tools 16

P

Playback Info Tab 19
Preview Drop Counter 21

Q

Quick Settings 11

R

Read Drop Counter 21
Resources 16

S

Scope 5
Simple Mode 7
Support 7
Synchronizing VCube Essentials with Pyramix 13
System Tab 17

T

Thank you 5
ToolTips 7

V

VCube Essentials Resources 16
Video and Audio Disk Read graphs 20
Vista 6

W

What is VCube Essentials? 8
Windows Vista 6